

INSTALLATION GUIDE

BR-AS35A HDD Anti-vibration

Please refer the assembly picture of hard disk driver anti-vibration as shown as below.

